

SWING CHAIR INSTRUCTION GUIDE AND SAFETY TIPS

The swing hangs from a single point. Examples of where you might install your swing chair are:

- Tree Limb
- Porch Ceiling (in heavy joist or heavy beam)
- Garden Arbour Beam
- Ceiling Joist or Heavy Beam (indoor or outdoor)
- Free Standing Swing Stand Frame – Check your local hardware store or building supply store. Search internet under “hammock stands.”

WEIGHT LIMIT

The weight limit for these swings is 250 lbs. Check with your local hardware store to be certain ALL hardware components mentioned below (chain, S-hooks, screw eye screw, threaded quick link) are adequate to support at least 250 lbs. or more.

HOW TO HANG A SWING CHAIR:

- **Tree Limb** – Loop a heavy rope or chain over a sturdy tree limb and attach the swing to the rope or chain with an “S” hook or threaded quick link.
- **Ceiling Joist or Beam**– Use a screw eye that is at least 3/8” in diameter with a threaded length of at least 3”. Install the screw eye the entire length of the threads into a strong ceiling joist or beam which will support at least 250 lbs. Attach an “S” (or threaded quick link) to the screw eye in the ceiling and the other “S” hook (or threaded quick link) to the swing chair.
- **NOTE:** The swing chair will stretch slightly when you first sit in it .Adjust the height accordingly.

SAFETY TIPS

1. When installing the swing, be sure the hardware and what it is attached to is strong enough to support the weight of the person using the swing. The weight limit of the swing is 250 lbs.
2. Each time you use your swing chair, check the knots, hardware, and all supports to make certain they are secure.
3. **NEVER** leave your child unattended in a swing chair. **THIS IS NOT A TOY.**
4. Although these fabrics are mildew and fade resistant, avoid prolonged exposure to sunlight and rain. Over time, sunlight and rain will weaken the fabric and strings. When not in use, we suggest you bring your swing chair indoors. Dry thoroughly before storage.